

## **Assembly Instruction for #36DD2U Double Door 2-Plex**



**Inventory:** The #36DD2U consists of (1) #DD36 double door (3) #136 panels (with fold down clips attached) (1) #F22W pre-drilled floor (2) #LC locking casters (2) #NLC non-locking casters (1) F22 middle floor (1) #124C lid (top) (20) #200 panel hinge clips (16) #250 floor divider clips (8) FDC fold down clips (4) CWC caster wheel clips *\*Note: Please make sure your entire inventory is complete.*

**Step 1:** Assemble the wheels onto the #F22W pre-drilled floor. Follow the ‘*pre-drilled floor and wheels*’ instructions enclosed with this shipment. After the wheels and floor are assembled unwrap the panels and stretch them out around the floor.

**Step 2:** Open the bottom door by unsnapping the (2) #200 panel hinge clips, and swing the door open. Raise the bottom left corner up until the door section is parallel and even with the floor pipe. Snap on a #250 floor divider clip on each side of the door’s opening to the floor’s pipe. Next, move to the left and snap on (2) #250 floor divider clips to the adjoining panel and the floor - between the 1<sup>st</sup> and 2<sup>nd</sup> bars from either side of the panel. (See *figure 1 below*). Continue with the remaining panels.

**Step 3:** On the panels inside the unit are #FDC fold down clips (2 per panel). 'Fold down' these clips flat. Place the middle floor on them with the pipe side up (flat side down). Snap a #250 floor divider clip on the center of each panel to the floor (See *figure 2 below*). On the door panels place a #250 floor divider clip on either side of the door where it opens.

**Step 5:** Place the lid on top of the unit and snap the (8) #200 panel clips to the enclosure

**Congratulations!** You are now ready to use your Rover Company #36DD2U 2-Plex enclosure.

Fig. 1



Fig. 2



Property of Rover Company

[www.roverpet.com](http://www.roverpet.com)

