



ENCLOSURE INSTRUCTIONS

- Unfold the section that has the door included. On all units higher than 24" there will be (3) #200 panel hinge clips on every panel. To determine the top from the bottom there will be (2) #200 panel hinge clips above the center bar on the panels, And on the 24" enclosures. The bars on the door panel are on top. The #200 panel hinge clip should have the open end facing inside the unit.
- Begin by placing the door where you want it to be. Move left around the cage from the door panel insuring that you have the correct end facing up.
- Unfold the sections and place the first panel of the following section (there will be no hinges on that side of the panel) and connect it to preceding panel.
- Square the enclosure in the desired shape and place the straight stabilizers (#180) and the corner stabilizers (#90) on the unit.
- Note #1: To remove the stabilizers hold one of the panels down and lift up on the other & the stabilizers will come off. **CAUTION:** Sometimes they may fly off depending on the force you lift the panels, so be careful.
- Note #2: If you have a panel lid you remove the stabilizers, they aren't needed.
- Note #3: If you have the optional floors and there are more than one, they will clip side by side (**Frame Side Up**) with (4) #250 floor divider clips down their common edge. Secure the floor in place to the outside panels with (1) #250 floor divider clip per panel.

Property of Rover Company

www.roverpet.com

