

## **ASSEMBLY INSTRUCTIONS FOR #F22W PRE-DRILLED FLOORS WITH WHEELS**



- 1) Make sure you have the correct amount of wheels for your #F22W4. There should be (1) #F22W4 pre drilled floor (2) #LC locking casters (2) #NLC non-locking casters (4) #CWC caster wheel clips (8) #250 floor divider clips.
- 2) Insert the wheel shaft through the pre-drilled holes on the floor section. Insert with the floor's pipe side up (flat side down – as shown in the above picture). **NOTE: The locking caster wheels should be on the same side of the floor.** Insert the locking wheels where the wheel holes are closest together – 8 inches from the corner ends. The locking wheels will go in the front of the enclosure unit.
- 3) With the wheel shaft sticking up from the pipe side, insert the wheel clip into and around the notch area on the wheel's shaft.
- 4) Continue installing the wheels as shown in the above steps. If there are two floors going side by side, (2'x4' or larger), make sure the outer corners have the locking wheels and the middle section has the non-locking wheels. With #250 floor divider clips attach the two floors together.

Congratulations! You are now ready to assemble the enclosure to the floor.

*\*NOTE: it is recommended to lock the wheels in place before attaching panels.*

### **CAUTION**

\*\*\* ONCE THE FLOORS ARE ASSEMBLED **DO NOT** WALK ON THEM \*\*\*

Property of Rover Company

**[www.roverpet.com](http://www.roverpet.com)**



