

Instructions for Replacing Door Pins on Triple 6' Doors

You will have a total of 4 pins. 2 are 2" long and tapered on both ends. 2 are 1 ½" and tapered on only 1 end. Longer pins are used for the middle section. The shorter pins are used on both ends (the tapered end is tapped in, the flat end faces out). **TAP IN THE SHORTER PIN GENTLY MAKING SURE TO LEAVE FLAT SIDE OF PIN EXPOSED SLIGHTLY.**

Replace middle section first. Take 1 long pin and tap into lower cross bar on frame where the hole is drilled. Now install the middle door. Next install the bottom door and tap in shorter pin in the bottom (leaving flat end of pin exposed slightly). Use a bead of super glue.

Take remaining long pin and tap into upper middle cross bar. Install the top door into the long pin. Finally tap shorter pin into the top end. Be sure to leave pin exposed slightly. Use a bead of super glue.

Property of Rover Company

www.roverpet.com

