

Instructions for Grate Floor with Support Frame & Caster Wheels



Inventory: The #Z1824S consists of (6) #118 panels (4) #90 corner stabilizers (2) #180 straight stabilizers (12) #200 panel hinges clips (1) #G22 grate (1) #GW246 wheeled frame (3) #NLC non locking casters (3) #LC locking casters (6) #CWC caster wheel clips (18) #250 floor divider clips (6) washers.

Step 1: Begin by inserting the wheel washer around the shaft of the wheel. Next insert the wheel's shaft up and into the holes on the frame. The locking caster wheels should go into the holes farthest from the ends. Slide the caster wheel clip onto and around the shaft notch protruding up from the pipe frame. Do this to all four corners.

Step 2: Unfold the panels you have purchased into the shape of a 2' x 4' and position them around the wheeled frame. Secure the enclosure to the frame by snapping on the #250 floor clips to the frame and the lower panel bar.

Step 3: Connect the (4) #90 corner stabilizers (2) #180 straight stabilizers to the top of the enclosure.

Congratulations! You are now ready to use your Rover Company #Z1824S enclosure.

Property of Rover Company

www.roverpet.com

