


Panel Dividing Instructions

Fig 1



Fig 2



First, determine where you will divide the enclosure. You will need to replace the #200 panel hinges (the normal clips that attach 2 panels together) with 2 #250 floor divider clips. Next, place the dividing panel(s) at the dividing point and attach (2) more #250 floor divider clips to the end of the dividing panel – attaching it to one of the main enclosure panels as shown in Fig. 1 above. #180 straight stabilizer will be snapped onto the main enclosure panels at the dividing point. (See figure 2). If adding floor panels attach the floor to the exterior by using a #250 floor divider clip for every exterior panel. **NOTE: This is optional if you plan to remove the floors frequently to clean them.*

To divide in the middle of a panel, for enclosure dimensions other than in 2-foot sections, determine the dividing points, and, on the panels where you are

dividing, clip on the #250 floor divider clips, as shown in figure 3 (one on top and one on the bottom). There will be 2 clips on either side.

Fig 3



Property of Rover Company

www.roverpet.com

