

# Roverpet #66PR – 6'x 6' Puppy Rail Assembly Instructions



## Inventory List for The Roverpet #66PR Puppy Rail System:

(2) #PR72LB 72" Long Support Bar      (2) #72CB 72" Long Crossbar      (2) #PRS66 Crossbar Support and  
(6) 2", 3", 4", 5", 6" or 8" high legs (depending on style of Roverpet Puppy Rail System ordered)


## Assembly Procedure

**Special Notes:** If your Roverpet 6'x6' whelping box consists of a door panel, it needs to be configured with the door located on the right or center of the whelping box side to allow door hinge clearance.



Assembly of the Roverpet Puppy Rail System needs to be done outside of your existing Roverpet whelping box, than installed into the whelping box once fully assembled.



- 1.) Unpack contents of shipping carton and compare to inventory list above.
- 2.) Install (4) legs of the Roverpet Puppy Rail System into the 4 small leg whole locations on both #PR72LB.




- 3.) Insert one end of the #72CB's into the large holes located near the ends of (1) #PR72LB. Slide the #72CB into the hole until about 4" is protruding through.



- 4.) Install the remaining (2) legs into the #PRS66 leg hole. Install one on each of the #72CB. Slide the #PRS66 onto the #72CB until centered on the #72CB. When installing the #PRS66, verify the legs of the #PRS66 are positioned the same as the legs of the #PR72LB.



- 5.) Install the second #PR72LB onto the two remaining ends of the #72CB's, using the same method as before. Make certain that all 4 legs installed in Step 2 are positioned in the same direction.



- 6.) Take the assembled Roverpet Puppy Rail System and lower one side of the rails into your Roverpet whelping box. Line up the #PR72LB connecting ends with the 2nd vertical bars of the whelping box panels.

**Note:** Make sure the #PR72LB connecting end will not be installed on a door panel, rotate the Roverpet Puppy Rail Assembly 90° to avoid attachment on door panel. Verify the legs will rest on the floor of your whelping box when installation is complete.



7.) Clip the #PR72LB connecting ends around the vertical bars.



8.) With the one side of the #PR72LB installed on the vertical bars, slide the high-side of the Roverpet Puppy Rail System down into the Roverpet whelping box. Make sure the #PR72LB connecting ends are installed in the same manner as in the prior step.



9.) Push the whole Roverpet Puppy Rail System down until all four legs are resting on the whelping box floor.



10.) Attach the #PRS66 connecting ends to the middle of the center whelping box panels. If your Roverpet whelping box is configured with the door panel centered on a side, slide the #PRS66 along the #72CB until it can be attached to an adjacent panel.

***Note: Pig Rails can reduce the risk of possible suffocation. Note: Puppies should be watched at all times when small.***



Congratulations, you are now ready to use your Roverpet Puppy Rail System with your Roverpet Whelping Box!

[www.roverpet.com](http://www.roverpet.com)  
Property of Roverpet